




# Using the App

## 1. Connect to the device


Welcome!  
With the Matoha app, you can control your instruments as well save and manage your data.




## 2. Scan & select your machine



## 4. Scan your sample and select the collection to save into (ask your supervisor).




## 6. Press Save. Hold Save if the garment is the same as the measurement before to pair them (add to previous).




## 3. Choose 'Measurement interface'

✓ Ready to measure!



## 5. Add sample information such as the composition.



# FabriTe<sub>by</sub> Matoha

## Quick reference guide

### Safety information

Please read the safety section in the user manual before using the device.



Keep device away from liquids



If any issue occurs, stop using the device and inform your supervisor





Do not touch the sensor surface




Use a clean, dry cloth to clean the sensor if dirty

## Instrument parts & operation



**Turn on:** plug in the power cable **Turn off:** unplug the power cable. **When starting,** the device will say “Calibrating”. **DO NOT** place any samples onto the sensor until the device shows “Ready”.



## Measuring DOs and DON'Ts



✓ **DO** push the sample onto the device and wait





✗ **DON'T** move your sample while scanning



✗ **DON'T** scan printed areas or labels.



✓ **DO** use thicker samples or fold thin samples.



✓ **DO** cover the detector fully. If the sample is too small, place it on the right-hand side.

For further help, please refer to the User Manual or e-mail us at [support@matoha.com](mailto:support@matoha.com) © 2021 Matoha Instrumentation Ltd.